

# FusionSolar Residential Smart PV Quick Guide


## (Three-phase PV+Storage Scenario and Smart Dongle Networking)

Issue: 01  
Date: 2022-09-05




### 1

## Networking



### 2

## Product Overview



Component	Model	Description
Inverter (master and slave)	SUN2000-3KTL-M1 SUN2000-4KTL-M1 SUN2000-5KTL-M1 SUN2000-6KTL-M1 SUN2000-8KTL-M1 SUN2000-10KTL-M1	A maximum of three inverters can be cascaded.
Energy storage system (ESS)	LUNA2000-(5-30)-S0	<ul style="list-style-type: none"> <li>5 kWh per battery module, system capacity up to 30 kWh when two ESSs are cascaded</li> <li>If there is only one ESS, it must be connected to the master inverter.</li> </ul>
Backup Box	Backup Box-B1	<ul style="list-style-type: none"> <li>AC input voltage range: Grid-tied (three-phase) 342-440 V; off-grid (single-phase) 220/230 V</li> <li>If there is only one Backup Box, it must be connected to the master inverter.</li> </ul>
Smart Power Sensor	DTSU666-H	<ul style="list-style-type: none"> <li>The Smart Power Sensor must be connected to the master inverter.</li> <li>It connects to the inverter over RS485 for output power management and power limiting.</li> </ul>
Smart Dongle	SDongleA-03 (4G) SDongleA-05 (WLAN-FE)	<ul style="list-style-type: none"> <li>The Smart Dongle must be connected to the master inverter.</li> <li>It connects to the management system and performs power scheduling.</li> </ul>
Smart PV Optimizer	SUN2000-450W-P SUN2000-600W-P	Long and short input cables are available to connect to PV modules with different cable lengths.

**NOTE**

- The information in this document is subject to change due to version upgrade or other reasons. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.
- For details about the solution components, installation, and cable connections, see the corresponding user manuals and quick guides.
- The cable colors involved in this document are for reference only. Select cables in accordance with local cable specifications.

# FusionSolar Residential Smart PV Quick Guide

## (Three-phase PV+Storage Scenario and Smart Dongle Networking)



### 3

## Cable Connections

#### DANGER


Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

#### NOTICE

Signal cables must be outdoor shielded twisted pair cables.


Port	Pin	Definition	Pin	Port
Master inverter COM	1	485A1-1	2	Slave inverter 1 COM
	3	485B1-1	4	
	5	Shield layer grounding	/	/
	7	RS485A, RS485 differential signal+	4	ESS 1 COM
	8	DIN1	X4-1	Backup Box
	9	RS485B, RS485 differential signal-	25	DTSU666-H
	11	Enable+	7	
	13	Enable-, GND	3	ESS 1 COM
	16	GND	2	
				X4-2

#### Critical load



#### Backup load power distribution box


**NOTICE**  
The wiring sequence of the Backup Box must be consistent with that of the inverter AC terminals.





#### Power grid




#### AC power distribution box




#### PV strings (including optimizers)



#### ESS 2 (power control module) and ESS 1 (power control module)



**NOTICE**  
Connect other cables to slave inverters by referring to the connection method for the master inverter.



Port	Pin	Definition	Pin	Port
ESS 2 COM	1	Shield layer grounding	1	ESS 1 COM
	2	Enable signal GND	2	
	3	Enable signal+	3	
	4	RS485A, RS485 differential signal+	4	
	7	RS485B, RS485 differential signal-	7	
	8	CANL, extended CAN bus interface	8	
	9	CANH, extended CAN bus interface	9	

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings
	2	Master inverter	PV1-	Negative terminal	PV strings
	3	ESS 1	BAT+	BAT+	ESS 1
Signal cable	4	Master inverter	COM	COM (on the right)	ESS 1
	5	ESS 2	COM (on the right)	COM (on the left)	ESS 1
	6	Slave inverter 1	COM-1	COM-2	Slave inverter 2
	7	Master inverter	AC-L1	X3-1 (L1)	Backup Box
		AC-L2	X3-3 (L2)		
		AC-L3	X3-5 (L3)		
		AC-N	X3-8 (N)		
AC power cable	7	Master inverter	AC-PE	X3-12 (PE)	Backup Box

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	8	Backup load power distribution box	L	X1-1	Backup Box
			N	X1-2	
			PE	X1-4	
AC power cable	9	AC power distribution box	L1	X2-1	Backup Box
			L2	X2-2	
			L3	X2-3	
			N	X2-4	
AC power cable	10	AC power distribution box	PE	X2-6	Smart Power Sensor
			L1	3	
			L2	6	
			L3	9	
AC power cable	11	AC power distribution box	N	10	Smart Power Sensor CT
			L1	13	
			L2	14	
			L2	16	
			L3	17	

# FusionSolar Residential Smart PV Quick Guide

## (Three-phase PV+Storage Scenario and Smart Dongle Networking)



### 4 System Commissioning

#### App-based Deployment Procedure

- Download and install the FusionSolar app
- ↓
- Sign up as an installer (optional, required for initial registration)
- ↓
- Enter setup wizard
- ↓
- Check the device status

#### Downloading and Installing the FusionSolar App

- Search for FusionSolar in the app store to download the app.
- Scan the QR code below to download the app.




FusionSolar

#### Installer Registration


##### Initial registration

Create the first installer account, and generate a domain named after the company.




##### Non-initial registration

To create multiple installer accounts for a company, log in to the FusionSolar app and tap **New user** to create an installer account.



#### Setup Wizard (Connecting to the Inverter WiFi for Commissioning)



# FusionSolar Residential Smart PV Quick Guide

## (Three-phase PV+Storage Scenario and Smart Dongle Networking)



### Set the energy storage working mode.

Working mode settings

Maximum self-consumption: [ ]  
Fully fed to grid: [ ]  
TOU: [ ]

Select an energy storage working mode.

You can tap ? on the screen for more information.

### Set the communication networking.

#### WLAN communication

Select the router you want to connect and enter the router password.

Or

#### 4G communication

By default, APN mode is set to Automatic. If you cannot access the Internet in the Automatic mode, set this to Manual. In this case, set the parameters related to the SIM card with the information obtained from the carrier.

#### FE communication

If the Ethernet parameter is displayed, the network cable is not connected. Reconnect the network cable.

### Add a plant.

### Create an owner account.

### Checking the Device Status

# FusionSolar Residential Smart PV Quick Guide


## (Three-phase PV+Storage Scenario and Smart Dongle Networking)



### 5 Physical Layout of Smart PV Optimizers


#### Attaching SN Labels

Remove the SN labels from optimizers and attach them to the physical layout template based on the actual positions of the optimizers in the plant.




#### Taking a Photo of the Physical Layout Template

Ensure that the four positioning points on the template are within the frame.




#### Generating a Physical Layout on the App

Enter the Plant Layout screen.



Upload the template and generate a layout.



If some QR codes cannot be identified or the plant layout needs to be adjusted, log in to the FusionSolar management system WebUI. For details, see "Creating a Physical Layout on the WebUI Manually."

