

Battery Compatibility Overview

This document lists the compatible batteries with all GoodWe storage inverters, consisting in 3 system types:

- 1) Low-voltage energy storage systems
- 2) High-voltage energy storage systems
- 3) Commercial and industrial energy storage systems

Only batteries listed in this document are approved for connection to GoodWe storage inverters according to GoodWe Limited Warranty.

1) Low-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series					
			ES	EM	SBP	ES G2	SBP G2	ES uinq
GOODWE	SECU-A	SECU-A5.4L	●	●	●	●	●	
	Lynx Home U ¹	LX U5.4-L	●	●	●	●	●	●
	Lynx Home U-20 ²	LX U5.4-20	●	●	●	●	●	●
	Lynx Home A ³	LX A5.0-10				●	●	●
ES/EM/SBP/BP: *1. ARM firmware versions 11 and above are required for compatibility. *2. ARM firmware versions 11 and above are required for compatibility.								
ES G2/SBP G2: *2. ARM firmware versions 02 and above are required for compatibility. *3. ARM firmware versions 07 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uinq
BYD	Battery-Box Pro Series ^{*1}	-	●	●	●	●	●	
	Battery-Box Res Series ^{*1}	-	●	●	●	●	●	
	Battery-Box LV Series ^{*2}	-	●	●	●	●	●	
	Battery-Box Premium LVL ^{*2}	LVL 15.4	●	●	●	●	●	●
	Battery-Box Premium LVS Series ^{*2}	-	●	●	●	●	●	
ES/EM/SBP/BP: *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uinq
LG	RESU LV Series	RESU 3.3 ^{*1}	●	●	●	●	●	
		RESU 6.5 ^{*1}	●	●	●	●	●	
		RESU 10 ^{*1}	●	●	●	●	●	
		RESU 12 ^{*2}	●	●	●	●	●	
		RESU 13 ^{*2}	●	●	●	●	●	
		RESU 6.4 EX ^{*1}	●	●	●	●	●	
ES/EM/SBP: *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uinq
PYLON	US2000 Series ^{*1}	US2000	●	●	●	●	●	
	US3000 Series ^{*2}	US3000	●	●	●	●	●	
	US2000C Series ^{*1}	US2000C	●	●	●	●	●	
	US3000C Series ^{*2}	US3000C	●	●	●	●	●	
	Force L1 Series ^{*2}	Force-L1	●	●	●	●	●	
	Force L2 Series ^{*2}	Force-L2	●	●	●	●	●	
	US5000 Series ^{*3}	US5000				●	●	
ES/EM/SBP/BP: *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility. *3. ARM firmware versions 00 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uinq
DYNESS	DYNESS-LV Series ^{*1}	DYNESS-LV x1	●	●	●			
		DYNESS-LV x2	●	●	●			
		DYNESS-LV x3	●	●	●			
		DYNESS-LV x4	●	●	●			
	POWERBOX F Series ^{*1}	POWERBOX F-2.5	●	●	●			
		POWERBOX F-5.0	●	●	●			
		POWERBOX F-7.5	●	●	●			
		POWERBOX F-10.0	●	●	●			
	DYNESS-LV Series	DL5.0C ^{*2}				●	●	●
		DL5.0X ^{*3}				●	●	●
	A48100 ^{*4}				●	●		
ES/EM/SBP/BP: *1. ARM firmware versions 07 and above are required for compatibility.								
ES G2/SBP G2: *2. ARM firmware versions 06 and above are required for compatibility. *3. ARM firmware versions 07 and above are required for compatibility. *4. ARM firmware versions 07 and above are required for compatibility.								

Battery Compatibility Overview

1) Low-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series		
			ES	EM	SBP
OLOID	LBS051100A Series ^{*1}	LBS051100A-A02	•		
		LBS051100A-A03	•		
	LBS051200A Series ^{*1}	LBS051200A-A02	•		
		LBS051200A-A03	•		
ES: ^{*1} . ARM firmware versions 12 and above are required for compatibility.					
Battery Brand	Battery Series	Battery Model	ES	EM	SBP
Soluna	LV(48V) Battery Series	Soluna 4K Pack	•	•	•
		Soluna 5K Pack	•	•	•
		Soluna EOS 5K Pack	•	•	•
Battery Brand	Battery Series	Battery Model	ES	EM	SBP
ALPHA ^{*1}	Smile5-BAT Series	SMILE5-BAT ^{*2}	•	•	•
	Smile-BAT Series	Smile-BAT-10.1P ^{*2}	•	•	•
		Smile-BAT-10.3P ^{*2}	•	•	•
		Smile-BAT-13.3P ^{*3}	•	•	•
	M48112-P Series	M48112-P ^{*3}	•	•	•
	M48100-P Series	M48100-P ^{*3}	•	•	•
ES/EM/SBP/BP: ^{*1} . CAN communication line sequence of ALPHA-ESS battery does not match GoodWe inverters. A matching solution provided by ALPHA-ESS is required. ^{*2} . ARM firmware versions 10 and above are required for compatibility. ^{*3} . ARM firmware versions 11 and above are required for compatibility.					
Battery Brand	Battery Series	Battery Model	ES	EM	SBP
Tecloman	Firefly Series ^{*1}	Firefly-3.6K	•	•	•
		Firefly-7.2K	•	•	•
		Firefly-10.8K	•	•	•
		Firefly-14.4K	•	•	•
		Firefly-18.0K	•	•	•
		Firefly-21.6K	•	•	•
		Firefly-25.2K	•	•	•
ES/EM/SBP: ^{*1} . ARM firmware versions 12 and above are required for compatibility.					
Battery Brand	Battery Series	Battery Model	ES	EM	SBP
UZENERGY	L051100-A Series	L051100-A ^{*1}	•	•	•
ES/EM/SBP: ^{*1} . ARM firmware versions 12 and above are required for compatibility.					

Battery Compatibility Overview

2) High-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series								
			ET (5-10kW)*	EH	BT	BH	EHB	ET (15-30kW)	ET G2	ET (40~50KW)	
GOODWE	Lynx Home F ^{*1} Lynx Home F PLUS+ ^{*2}	LX F6.6-H	●	●	●	●	●	●	●	●	
		LX F9.8-H	●	●	●	●	●	●	●	●	
		LX F13.1-H	●	●	●	●	●	●	●	●	
		LX F16.4-H	●		●				●	●	
	Lynx Home F G2 ^{*3}	LX F6.4-H-20			●		●				
		LX F9.6-H-20	●	●	●	●	●			●	
		LX F12.8-H-20	●	●	●	●	●			●	
		LX F16.0-H-20	●	●	●	●	●			●	
		LX F19.2-H-20	●	●	●	●	●			●	
		LX F22.4-H-20	●		●					●	
		LX F25.6-H-20	●		●					●	
	Lynx C ^{*4}	GW60KWH-D-10							●		
		GW100KWH-D-10									●
		GW100KWH-D-10 (Extension)									●
		LX C101-10									●
		LX C120-10									●
		LX C138-10									●
	Lynx Home D ^{*5}	LXD5.0-10	●		●				●	●	

*. Including ET Series: ET PLUS+, ET PLUS+ (16A)

ET/EH/BT/BH/EHB:

*1. ARM firmware versions 19 and above are required for compatibility.

*2. ARM firmware versions 23 and above are required for compatibility.

*3. For compatibility, the ET/BT series requires ARM25 and DSP09 versions and above; the EHB series requires ARM25 and DSP version 03 and above; the EH/BH series requires ARM25 and DSP version 07 and above.

*5. For compatibility, the ET/BT series requires ARM28 and DSP version 12 and above.

ET (15-30KW)/ET G2:

*3. For compatibility, the ET (15~30K) Series requires ARM07 and DSP version 06 and above.

*4. For compatibility, the ET (15~30K) series requires ARM07 and above.

*4. ET 50KW with Lynx C-Series LX C101-10, LX C120-10 cannot reach the maximum power of the inverter.

*5. For compatibility, the ET(15~30K) series requires ARM 09 and DSP version 08 and above.

Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	BH	EHB	ET (15-30kW)	ET G2	ET (40~50KW)
BYD	Battery-Box HV Series ^{*1}	-	●	●	●	●				
	Battery-Box Premium HVM ^{*2}	HVM 8.3		●		●	●			
		HVM 11.0	●	●	●	●	●	●	●	
		HVM 13.8	●	●	●	●	●	●	●	
		HVM 16.6	●	●	●	●	●	●	●	
		HVM 19.3	●	●	●	●	●	●	●	
		HVM 22.1	●	●	●	●	●	●	●	
	Battery-Box Premium HVS ^{*2}	HVS 5.1	●	●	●	●	●	●	●	
		HVS 7.7	●	●	●	●	●	●	●	
		HVS 10.2	●	●	●	●	●	●	●	
		HVS 12.8	●		●				●	●

*. Including ET Series: ET PLUS+, ET PLUS+ (16A)

ET/EH/BT/BH/EHB:

*1. ARM firmware versions 07 and above are required for compatibility.

*2. ARM firmware versions 11 and above are required for compatibility.

ET15~30K:

*2. ARM firmware versions 02 and above are required for compatibility.

BYD CAN communication line PIN1/2 corresponds to inverter CAN communication line PIN4/5.

*2. The maximum charge/discharge current of single-cluster HVS battery is 25A, ET30K with single-cluster HVS battery will not be able to reach the nominal maximum charge/discharge power of the inverter. ET15~30 series with HVM battery maximum charging and discharging current of 40A.

Battery Compatibility Overview

2) High-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Wechselrichterserie						
			ET (5-10kW)*	EH	BT	BH	EHB	ET G2	ET (40~50KW)
LG	RESU FLEX Series ^{*1}	FLEX 8.6	●						
		FLEX 12.9	●						
		FLEX 17.2	●						
	RESU Type-R Series	RESU10H_Type-R					●		
	RESU Prime Series ^{*2}	RESU10H Prime					●		
		RESU16H Prime					●		
<p>*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH/EHB: ^{*1.} Only compatible with ET PLUS+ Series. ARM firmware versions 23 and above are required for compatibility. ^{*2.} ARM firmware versions 20 and above and DSP versions 02 and above are required for compatibility.</p>									
Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	BH	EHB	ET G2	ET (40~50KW)
PYLON	Powercube H1 Series ^{*1}	POWERCUBE-H1-48	●	●	●	●			
	Force H1 Series ^{*2}	Force-H1	●	●	●	●		●	
	Force H2 Series ^{*3}	Force-H2	●	●	●	●		●	
	Force H3 Series ^{*4}	Force-H3	●	●	●	●		●	
<p>*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH: ^{*1.} ARM firmware versions 07 and above are required for compatibility. Please note that the nominal voltage of POWERCUBE-H1-48 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 8 units for EH/BH, and 11 units for ET/BT. ^{*2.} ARM firmware versions 14 and above are required for compatibility. ^{*3.} When the 4-module FORCE-H1 is undervoltage, the battery voltage will be lower than 180V, so a minimum of 5 modules are required to match the ET. ^{*4.} ARM firmware versions 14 and above are required for compatibility. Please note that the nominal voltage of Force H3 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 4 units for EH/BH, and 5 units for ET/BT. ET G2: ^{*4.} Please note that the nominal voltage of Force H3 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 6 units for ET G2.</p>									
Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	BH	EHB	ET G2	ET (40~50KW)
DYNESS	Tower Series ^{*1}	Tower T7		●		●		●	
		Tower T10	●	●	●	●	●		
		Tower T14	●	●	●	●	●		
		Tower T17	●		●		●		
		Tower T21					●		
	Tower Pro Series ^{*2}	Tower Pro TP7						●	
		Tower Pro TP11	●		●			●	
		Tower Pro TP15	●		●			●	
		Tower Pro TP19	●		●			●	
		Tower Pro TP23						●	
Power Rack-HV4F	Power Rack-HV4F-11s							●	
<p>*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH: ^{*1.} ARM firmware versions 10 and above are required for compatibility. ^{*2.} ARM firmware versions 10 and above are required for compatibility. ET G2: ^{*1.} ARM firmware versions 01 and above are required for compatibility. ^{*2.} ARM firmware versions 01 and above are required for compatibility.</p>									

Battery Compatibility Overview

Battery Brand	Battery Series	Battery Model	Inverter Series					
			ET (5-10kW)*	EH	BT	BH	ET G2	ET (40~50KW)
Soluna	HV Battery Series ^{†1}	Soluna 7K Pack HV		●		●		
		Soluna 10K Pack HV	●	●	●	●		
		Soluna 15K Pack HV	●		●			
*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH/EHB: †1. ARM firmware versions 10 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	BH	ET G2	ET (40~50KW)
iPotisEdge	Mint-JKE ^{†1}	Mint-JKE5		●		●		
		Mint-JKE10		●		●		
		Mint-JKE15	●	●	●	●		
		Mint-JKE20	●	●	●	●		
*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH/EHB: †1. ARM firmware versions 12 and above are required for compatibility.								
Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	BH	ET G2	ET (40~50KW)
WTS	WTS Power-CORE 1.0 ^{†1}	WTS Power-CORE 1.0-5.5						
		WTS Power-CORE 1.0-8.3	●		●			
		WTS Power-CORE 1.0-11.0	●		●			
		WTS Power-CORE 1.0-13.8	●		●			
	WTS Energy-CORE 1.0 ^{†1}	WTS Energy-CORE 1.0-9.6						
		WTS Energy-CORE 1.0-12.8	●		●			
		WTS Energy-CORE 1.0-16.0	●		●			
		WTS Energy-CORE 1.0-19.2	●		●			
		WTS Energy-CORE 1.0-22.4	●		●			
WTS Energy-CORE 1.0-25.6	●		●					
ET/BT: †1. ARM firmware versions 14 and above are required for compatibility.								

3) Commercial and Industrial Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series	
			ETC	BTC
GOODWE	Lynx C series ^{†1}	LX C 101-10	●	●
		LX C 120-10	●	●
		LX C 138-10	●	●
		LX C 156-10	●	●
ETC 50K/BTC 50K: †1. EMS firmware versions 02 and above are required for compatibility. ETC 100K: †1. EMS firmware versions 00 and above are required for compatibility.				